


## WLAN Module F/W downloads

1. Connect Host PC to Printer with same network.
2. Execute 'BasicConfigureTool\_new.exe'.
3. Select 'Connect WLAN', and input printer's IP, ID/Password.  
(Default ID: admin, PW: password)
4. Click 'Connect' button.



5. Select 'Firmware',

and then you can download WLAN F/W(WLAN\_M\_STANDARD\_v1.4.bin).

