

Quick WiFi Installation guide.

Please install the printer driver before starting to configure your PC.

Install on your PC or laptop the BTP2002NP printer with the printer installer, which you can find on the Orient BTP2002NP Driver and Utilities CD.

To configure TCP/IP for static addressing

1. Open Network and Dial-up Connections on your PC / Laptop
2. Right-click the network WiFi connection you want to configure, and then click **Properties**.
3. On the **General** tab (for a local area connection) or the **Networking** tab (all other connections), click **Internet Protocol (TCP/IP)**, and then click **Properties**.
4. Click **Use the following IP address**, and do one of the following:
 - For a local area connection, in **IP address**, **Subnet mask**, and **Default gateway**, type the **IP address 192.168.0.100**, **subnet mask 255.255.255.0**, and default gateway addresses will be empty.
5. Close all applications and restart Pc.
6. Make sure printer is On and ready
7. Open Network and Dial-up Connections on your PC / Laptop
8. Double click on the network WiFi connection you want to select.
9. Select in your WiFi connection the printer (**defaultSSID**) (default no password require) and click **connect**.
10. Go to Start, Settings, Printers and Faxes.
11. Right click on BTP2002NP and go to **properties**.
12. Select **ports** and **add port**.
13. Select **standard TCP/IP Port**
14. New port (Wizard)
15. Type for **printer name or ip address** 192.168.0.200
16. Device type (**Generic Network Card**)
17. Finish
18. Close all open screens
19. Go to Start, Settings, Printers and Faxes.
20. Right click on BTP2002NP and go to **properties**, click **print test page**.

Note

- To open Network and Dial-up Connections, click **Start**, point to **Settings**, and then click **Network and Dial-up Connections**.
- You must be logged on as an administrator or a member of the Administrators group in order to complete this procedure.