

### How To Use the Price Checker Demonstration Program “PCDemo.exe”

This utility can be used for a five minutes set-up demonstration, as well as or for experimenting. You can literally see, what is sent to a Price checker or what is received from it. Just connect to your Price checker and try it. It's really that easy!

#### Some notes:

1. Regarding the Network Connection Properties of your PC: Make sure the IP address of your PC is in the same IP range as the price checker you want to demo.  
For instance by giving your PC IP address: 192.168.3.32 (this is the default value).
2. Set the Price checker in Server Mode as described in Chapter 5.5 of the Price checker User's Manual  
(this is the default setting)
3. If this appears to be necessary: - Turn off your Windows firewall or  
- Add Price checker Demo.exe and Price checker Config.exe in the list of Exceptions under Windows Firewall.

You can manually enter text, which is displayed on the price checker screen. Just click on the blue edit screen of this program and start typing.

#### ***Don't forget to 'Connect' first!***

You can also give Price checker Control (ESC) commands. Just hit the ESC key, which sends an actual esc-character (0x1b).

Examples:

**Clearing the Price checker screen:** Hit 'ESC' key  
Enter '%'

**Kicking the Price checker into Sleep:** Hit 'ESC' key  
Enter '@'

**Waking up the Price checker again:** Hit 'ESC' key  
Enter Capital A

Check Appendix B for more ESC command examples.

When you scan a barcode, the program responds with 1 of 5 predefined texts. On the blue edit field you can actually see what exactly is received or transmitted.

Make sure the price checker runs in TCP-Server mode, before you try this program. You have to run the Configuration Utility (PriceChecker Config Tool) to accomplish this. See \ Configuration Tool \ PCCTConfigSetup40216b.exe.