





Test Printer OPOS Driver SOP.

1. Please entry A path “C:\Program Files\Microsoft Point of Service\SDK\Samples\Sample Application” and then execute TestApp AP.



2. Please select A “IFD00x 01” and then select B “Open”.



3. Please select A “Claim”, enable B “Device Enabled” option, and then select C “Print Normal”.

